

6 Steps To Prep and Spot Prime Door Ding Repairs

Step 1	Block Sand Repair Area With 320 Grit
Step 2	Wipe Off With Wax and Grease Remover
Step 3	Spot Prime Repair Area
Step 4	Block Sand Primer and Paint Area With 400 Grit
Step 5	Sand Clear Coat Area With 800 Grit
Step 6	Sand Blend Area With 1200 Grit

[Print This In Description](#)