



Block Sanding Body Filler

36 Grit	Coarse: Level and Shapes: Used First On Large Repair Areas To Level and Shape Filler
80 Grit	Medium: Level and Shapes: Use First On Small Repair Areas To Level and Shape Filler. Or Use To Minimize 36 Grit Scratches On Large Repair Areas.
150 - 220 Grit	Medium/Fine: Smooths: Used To Smooth and Minimizes 80 Grit Scratches Before Applying Primer.

NOTE: All Body Filler Should Be Smoothed With 150 Grit to 220 Grit Before Applying Primer